

Instructions for interior cedar wall kit

Step #1: Using the finishing nails supplied, nail the 1 x 6 x 30" tongue and groove cedar boards to the lower wall section making sure to keep the boards level. When you get to a wall joint, cut the last board to fit. Do this on all sides of the gazebo except the door wall. Using the same procedure for the 11" tongue and groove boards attach them to the top wall section, also do the door wall.

Step #2: Nail the 48- 3/4" long cedar boards to the top and bottom of the window opening keeping the board flush with the interior cedar wall paneling. Nail the 44-3/4" long cedar boards to the sides of the window opening keeping the board flush with the interior cedar wall paneling.

Step #3: Attach the 87" long tongue and groove boards to the door section using 2 boards for each side of the door. One board for each side of the door will need to be cut to the correct width.

Step #4: Attach the 74-3/4" long cedar boards to the sides of the door jam keeping the board flush with the interior cedar wall paneling. Attach the 33-1/2" long cedar boards to the top and bottom of the door jam. Attach the 35" long cedar board to the 2 x 4 below the door.

Step #5: Fasten the 1 x 4 x 87" cedar boards to each wall intersection to finish corners.

Step #6: To preserve the beauty of your cedar you should stain or varnish it within a few days.