

12 Ft PRINCESS GAZEBO
INSTRUCTIONS FOR ASSEMBLY

Norfab has taken great care to ensure all parts are of quality material and complete. Please check the unit over carefully. Should you experience any problems **DO NOT CALL** the STORE! Contact Norfab immediately at 1 800 465 2918 and they will look after you.

Updated January 3 2001

Tools required for construction: hammer, Philips and No. 2 - Robertson screwdrivers or drill bits, utility knife, step ladder, tape measure, saw, stapler, and sand paper.

PLEASE READ INSTRUCTIONS CAREFULLY

Step 1:


Make sure that the construction site is large enough to accommodate the gazebo. The structure when completed is 9'6" high and is 12' in diameter. The building site should be level to ensure proper fit of gazebo components.

Step 2:

Unpack the gazebo. Please handle the lattice panels carefully. Use the materials list, found at the end of these instructions, to identify each part and group all wall panels and roof components in their respective groups. If you have any questions please contact Norfab at 1-800-465-2918 between 8:00 a.m. - 5:00 p.m., Monday to Friday and 8:30 a.m.- 3:30 p.m. Saturday, central time.


Step 3:

Level the area where the gazebo is to stand. Erect the entrance in the desired location. Stand the remaining panels up, fastening them together with three 3" screws, one at the top, middle and bottom of each wall panel. If the panels do not line up properly, check to ensure your base is level.




Step 4:

Insert top and bottom lattice sections into wall panels and nail with finishing nails supplied.



Step 5


To erect the roof, take the roof peak (piece of 3" pipe, 3 3/4" long) and screw two rafters to it on opposite sides of the pipe using two screws for each rafter, keeping top of pipe flush with top of rafter. Place the two assembled rafters across the gazebo diagonally at the panel joints. The notch at the tail end of the rafter should fit snug against the outer edge of the wall perimeter. Make sure the center of the rafters line up with the panel joints. If the notch does not fit snug, either push wall out or the roof peak up, to make them fit well.



Fasten each rafter to the wall panel joints with 3" nails. Fasten remaining rafters to roof peak with two screws in each rafter and two nails fastening rafter to wall perimeter.


Step 6:

Install fascia boards. The top of the fascia board should be flush with the top of the rafter.



Step 7:

Sheath the roof with 1/2" plywood, keeping the bottom edge of the plywood flush with the fascia. It is important when installing the roof sheathing that each section of plywood meets its adjacent section at the center of each roof rafter. Install all of the largest sheets of plywood first, place the H clips (not shown) between the upper and lower sheets, and then proceed to install the triangular pieces at the peak of the roof, and finally the small wedges at the base of the roof (It's a good idea to just tack the roof sheathing until all are in place as you may have to move them up or down to achieve proper fit.). If you climb on the roof for any reason, distribute your weight onto the roof rafters. Shingle roof with your choice of shingles.








Step 8:






Nail the 16 vertical corner boards to the seams on each wall joint.

Step 9:

To preserve the beauty of your cedar Gazebo you must stain or varnish it within a few days of installation. You may want to sand any rough edges, and stamps, to produce a better finish.

Materials List for the 12' PRINCESS Gazebo

QTY	DESCRIPTION	
Wall Panels:	7	Wall panels
		
	1	Door panel
		
8	Upper Lattice panels	
8	Lower Lattice panels	
Roof Components:	1	Roof peak (3 3/4" piece of 3" pipe)
		

- 8 Rafters 
- 8 1/2" plywood triangles 
- 8 1/2"plywood sheathing 
- 8 1/2"plywood wedges 
- 8 Cedar fascia boards 

Other:

- 1 H Clips
- 1 Bag 3" nails
- 1 Bag 2" nails
- 1 Bag finishing nails
- 1 Bag 3" screws

Inspected by: _____ Date: _____