

10' x 8' NORFAB Floor Kit Instruction Manual

(Actual floor size is 10' wide x 7' 8-1/4" long)

STEP 1:

Assemble the 2" x 4" floor frame by placing the 96" treated 2" x 4", **on edge**, attach the two 24" pieces with nail, making it a 10' frame and inserting the six treated 2" x 4" x 89 1/4" pieces between them, spacing them at 24" on center. Ensure the stud is placed at the joint of the 24" piece. Nail the outer plates to the ends of each 89 1/4" long studs with two 3" coated nails. Ensure that all studs are nailed flush with the adjoining plates.

STEP 2:

Level the desired site of your new shed. It is suggested that you use 3 - 4" x 4" x 10' long treated posts (not supplied) to level the site and raise the floor off of the ground. Arrange these blockings as shown here.

STEP 3:

Place the 48" x 96" and 44-1/4" x 96" sheets of plywood on top of the frame, perpendicular to the 89 1/4" studs. Ensure that all edges of the plywood are flush with the frame before nailing the plywood to the frame with 1" coated nails. Nails should be placed at 12" intervals around the perimeter and along each stud.

* See separate Shed Instructions for shed assembly.

Materials Checklist

- 1 - bag 1" coated nails, 1 - bag 3" nails
- 1 - 1 x 4 x 92 1/4" (see note)
- 2 - 2 x 4 x 24" PWF
- 2 - 2 x 4 x 96" PWF
- 6 - 2 x 4 x 89 1/4" PWF
- 1 - 48" x 96" Floor Sheathing
- 1 - 44 5/8" x 96" Floor Sheathing
- 1 - 24" x 92 1/4" Floor Sheathing

***NOTE: Door to go on the 10' side.**

** If you are using this floor for a metal building, attach 1"x 4"x 92 1/4" to the short side.

